

<u>Option 1-A</u>	<u>Westchester Gray</u>	<u>Analytical Gray</u>	<u>Tricorn Black</u>
(old scheme 9)	SW 2849	SW 7051	SW 6258
	LRV 19	LRV 47	LRV 3
	314-C7	246-C2	251-C1
<u>Option 1-B</u>		<u>Snowbound</u>	<u>Chelsea Gray</u>
		SW 7004	SW 2850
		LRV 83	LRV 47
		256-C2	314-C8
<u>Option 1-C</u>		<u>Extra White</u>	<u>Polished Mahogany</u>
		SW 7006	SW 2838
		LRV 86	LRV 3
		257-C1	313-C4
<u>Option 1-D</u>		<u>Fleur de Sel</u>	<u>Cyberspace</u>
		SW 7666	SW 7076
		LRV 72	LRV 6
		258-C3	235-C7
<u>Option 2-A</u>	<u>Summit Gray 4</u>	<u>Extra White</u>	<u>Greenblack</u>
	SW 7669	SW 7006	SW 6994
	LRV 30	LRV 86	LRV 4
	282-C5	257-C1	251-C6
<u>Option 2-B</u>		<u>Alabaster</u>	<u>Rockwood Dark Red</u>
		SW 7008	SW 2801
		LRV 82	LRV 3
		255-C2	309-C1
<u>Option 2-C</u>		<u>Ivory Lace</u>	<u>Web Gray</u>
		SW 7013	SW 7075
		LRV 79	LRV 13
		254-C3	235-C6
<u>Option # 2-D</u>		<u>Passive</u>	<u>Mount Etna</u>
		SW 7064	SW 7625
		LRV 60	LRV 6
		236-C1	279-C2
<u>Option 3-A</u>	<u>Sanderling</u>	<u>Marshmallow</u>	<u>Fiery Brown</u>
	SW 7513	SW 7001	SW 6055
	LRV 31	LRV 82	LRV 5
	248-C5	267-C1	194-C7
<u>Option 3-B</u>		<u>Downy</u>	<u>Rugged Brown</u>
		SW 7002	SW 6062
		LRV 81	LRV 7
		267-C3	195-C7
<u>Option 3-C</u>		<u>Greek Villa</u>	<u>Enduring Bronze</u>
		SW 7551	SW 7055
		LRV 84	LRV 7
		254-C1	246-C7
<u>Option 3-D</u>		<u>Paperwhite</u>	<u>Greenblack</u>
		SW 7105	SW 6994
		LRV 87	LRV 4
		262-C1	251-C6

<u>Option 4-A</u>	<u>Colonial Revival Stone</u>	<u>Marshmallow</u>	<u>Rock Bottom</u>
(old scheme 11)	SW 2827	SW 7001	SW 7062
	LRV 31	LRV 82	LRV 7
	312-C6	267-C1	278-C2
<u>Option 4-B</u>		<u>Westhighland White</u>	<u>Fairfax Brown</u>
		SW 7566	SW 2856
		LRV 86	LRV 7
		255-C3	315-C5
<u>Option 4-C</u>		<u>Ivory Lace</u>	<u>Rockwood Shutter Green</u>
		SW 7013	SW 2809
		LRV 79	LRV 4
		254-C3	310-C1
<u>Option 4-D</u>		<u>Pure White</u>	<u>Griffin</u>
		SW 7005	SW 7026
		LRV 84	LRV 13
		255-C1	241-C6
<u>Option 5-A</u>	<u>Tony Taupe</u>	<u>Wool Skein</u>	<u>Polished Mahogany</u>
	SW 7038	SW 6148	SW 2838
	LVR 37	LRV 63	LRV 3
	249-C3	207-C1	313-C4
<u>Option 5-B</u>		<u>Aesthetic White</u>	<u>Greenblack</u>
		SW 7035	SW 6994
		LVR 73	LRV 4
		259-C4	251-C6
<u>Option 5-C</u>		<u>Alabaster</u>	<u>Iron Ore</u>
		SW 7008	SW 7069
		LRV 82	LRV 6
		255-C2	251-C7
<u>Option 5-D</u>		<u>China Doll</u>	<u>Chateau Brown</u>
		SW 7517	SW 7510
		LRV 63	LRV 8
		250-C1	242-C7
<u>Option 6-A</u>	<u>Rare Gray</u>	<u>Casa Blanca</u>	<u>Pewter Green</u>
	SW 6199	SW 7571	SW 6208
	LRV 38	LRV 76	LRV 12
	216-C3	264-C4	217-C6
<u>Option 6-B</u>		<u>Muslin</u>	<u>Cityscape</u>
		SW 6133	SW 7067
		LRV 74	LRV 22
		263-C5	236-C5
<u>Option 6-C</u>		<u>Aged White</u>	<u>Attitude Gray</u>
		SW 9180	SW 7060
		LRV 24	LRV 20
		261-C4	237-C5
<u>Option 6-D</u>		<u>Sedate Gray</u>	<u>Thunderous</u>
		SW 6169	SW 6201
		LRV 61	LRV 15
		211-C1	216-C6

<u>Option 7-A</u>	<u>Dorian Gray</u>	<u>Marshmallow</u>	<u>Iron Ore</u>
	SW 7017	SW 7001	SW 7069
	LRV 39	LRV 82	LRV 6
	244-C3	267-C1	251-C7
<u>Option 7-B</u>		<u>Creamy</u>	<u>Black Fox</u>
		SW 7012	SW 7020
		LRV 81	LRV 7
		261-C3	244-C7
<u>Option 7-C</u>		<u>Pure White</u>	<u>Raisin</u>
		SW 7005	SW 7630
		LRV 84	LRV 3
		255-C1	252-C3
<u>Option 7-D</u>		<u>Repose Gray</u>	<u>Chateau Brown</u>
		SW 7015	SW 7510
		LRV 58	LRV 8
		244-C1	242-C7
<u>Option 8-A</u>	<u>Chelsea Gray</u>	<u>Westhighland White</u>	<u>Grays Harbor</u>
	SW 2850	SW 7566	SW 6236
	LRV 47	LRV 86	LRV 6
	314-C8	255-C3	222-C6
<u>Option 8-B</u>		<u>Alabaster</u>	<u>Dark Night</u>
		SW 7008	SW 6237
		LRV 82	LRV 4
		249-C1	222-C7
<u>Option 8-C</u>		<u>Creamy</u>	<u>Inkwell</u>
		SW 7012	SW 6992
		LRV 83	LRV 4
		261-C3	251-C4
<u>Option 8-D</u>		<u>Fleur de Sel</u>	<u>Rockwood Shutter Green</u>
		SW 7666	SW 2809
		LRV 72	LRV 4
		258-C3	310-C1
<u>Option 9-A</u>	<u>Repose Gray</u>	<u>Downy</u>	<u>Black Fox</u>
	SW 7015	SW 7002	SW 7020
	LVR 58	LRV 81	LRV 7
	244-C1	267-C3	244-C7
<u>Option 9-B</u>		<u>Pure White</u>	<u>Westchester Gray</u>
		SW 7005	SW 2849
		LVR 84	LRV 19
		255-C1	314-C7
<u>Option 9-C</u>		<u>Incredible White</u>	<u>Cyberspace</u>
		SW 7028	SW 7076
		LRV 74	LRV 6
		256-C4	235-C7
<u>Option 9-D</u>		<u>Snowbound</u>	<u>Homburg Gray</u>
		SW 7004	SW 7622
		LRV 83	LRV 15
		256-C2	238-C7

<u>Option 10-A</u>	<u>Moderate White</u>	<u>Dover White</u>	<u>Rock Bottom</u>
	SW 6140	SW 6385	SW 7062
	LRV 74	LRV 83	LRV 7
	266-C3	261-C2	278-C2
<u>Option 10-B</u>		<u>Creamy</u>	<u>Roycroft Bottle Green</u>
		SW 7012	SW 2847
		LRV 81	LRV 51
		261-C3	314-5
<u>Option 10-C</u>		<u>Alabaster</u>	<u>Greenblack</u>
		SW 7008	SW 6994
		LRV 82	LRV 4
		255-C2	251-C6
<u>Option 10-D</u>		<u>Softer Tan</u>	<u>Darkroom</u>
		SW 6141	SW 7083
		LRV 60	LRV 5
		206-C1	227-C7
<u>Option # 11-A</u>	<u>Rugged Brown</u>	<u>Tony Taupe</u>	<u>Black Fox</u>
(old scheme 5)	SW 6062	SW 7038	SW 7020
	LRV 7	LRV 37	LRV 7
	195-C7	249-C3	244-C7
<u>Option # 11-B</u>		<u>Cultured Pearl</u>	<u>Caviar</u>
		SW 6028	SW 6990
		LRV 73	LRV 3
		260-C3	251-C2
<u>Option # 11-C</u>		<u>Polite White</u>	<u>Domino</u>
		SW 6056	SW 6989
		LRV 74	LRV 3
		274-C1	252-C5
<u>Option # 11-D</u>		<u>Downy</u>	<u>Black Bean</u>
		SW 7002	SW 6006
		LRV 81	LRV 4
		267-C3	252-C2
<u>Option # 12-A</u>	<u>Suitable Brown</u>	<u>Mega Greige</u>	<u>Urbane Bronze</u>
(old scheme 10)	SW 7054	SW 7031	SW 7048
	LRV 10	LRV 37	LRV 8
	246-C6	243-C3	245-C7
<u>Option # 12-B</u>		<u>Analytical Gray</u>	<u>Darkroom</u>
		SW 7051	SW 7083
		LRV 47	LRV 5
		246-C2	227-C7
<u>Option # 12-C</u>		<u>Agreeable Gray</u>	<u>Mega Greige</u>
		SW 7029	SW 7031
		LRV 60	LRV 37
		243-C1	243-C3
<u>Option # 12-D</u>		<u>Dover White</u>	<u>Deep Forest Brown</u>
		SW 5375	SW 9175
		LRV 83	LRV 4
		261-C2	252-C4

<u>Option # 13-A</u>	<u>Brainstorm Bronze</u>	<u>Dapper Tan</u>	<u>Black Fox</u>
(old scheme 8)	SW 7033	SW 6144	SW 7020
	LRV 14	LRV 22	LRV 7
	243-C6	206-C5	244-C7
<u>Option # 13-B</u>		<u>Downy</u>	<u>Greenblack</u>
		SW 7002	SW 6994
		LRV 81	LRV 4
		267-C3	251-C6
<u>Option # 13-C</u>		<u>White Duck</u>	<u>Iron Ore</u>
		SW 7010	SW 7069
		LRV 74	LRV 6
		254-C5	251-C7
<u>Option # 13-D</u>		<u>Incredible White</u>	<u>Black Bean</u>
		SW 7028	SW 6006
		LRV 74	LRV 4
		256-C4	252-C2
<u>Option # 14-A</u>	<u>High Tea</u>	<u>Downing Sand</u>	<u>Deep Forest Brown</u>
	SW 6159	SW 2822	SW 9175
	LRV 17	LRV 52	LRV 3
	210-C6	311-C4	252-C4
<u>Option # 14-B</u>		<u>Nacre</u>	<u>Dark Night</u>
		SW 6154	SW 6237
		LRV 76	LRV 4
		263-C2	227-C7
<u>Option # 14-C</u>		<u>Polite White</u>	<u>Perle Noir</u>
		SW 6056	SW 9154
		LRV 74	LRV 8
		274-C1	226-C7
<u>Option # 14-D</u>		<u>Ramie</u>	<u>Rockweed</u>
		SW 6156	SW 2735
		LRV 44	LRV 4
		210-C2	252-C1
<u>Option 15-A</u>	<u>Backdrop</u>	<u>Gray Area</u>	<u>Urbane Bronze</u>
(old scheme 1)	SW 7025	SW 7052	SW 7048
	LRV 20	LRV 39	LRV 8
	241-C5	246-C3	245-C7
<u>Option 15-B</u>		<u>Simple White</u>	<u>Dark Clove</u>
		SW 7021	SW 9183
		LRV 70	LRV 5
		260-C7	277-C4
<u>Option 15-C</u>		<u>Marshmallow</u>	<u>Turkish Coffee</u>
		SW 7001	SW 6076
		LRV 82	LRV 5
		267-C1	277-C3
<u>Option 15-D</u>		<u>Alpaca</u>	<u>Black Fox</u>
		SW 7022	SW 7020
		LRV 57	LRV 7
		241-C1	244-C7

Option 16-A	<u>Virtual Taupe</u>	<u>Accessible Beige</u>	<u>Rustic Red</u>
(old scheme 7)	SW 7039	SW 7036	SW 7593
	LRV 20	LRV 58	LRV 6
	249-C5	249-C1	275-C6
<u>Option 16-B</u>		<u>Wool Skein</u>	<u>Rockwood Red</u>
		SW 6148	SW 2802
		LRV 63	LRV 5
		207-C1	309-C2
<u>Option 16-C</u>		<u>Relaxed Khaki</u>	<u>Ripe Olive</u>
		SW 6149	SW 6209
		LRV 50	LRV 6
		207-C2	217-C7
<u>Option 16-D</u>		<u>Greek Villa</u>	<u>Muddled Basil</u>
		SW 7551	SW 7745
		LRV 84	LRV 9
		254-C1	211-C7
<u>Option 17-A</u>	<u>Warm Stone</u>	<u>Wool Skein</u>	<u>Darkroom</u>
	SW 7032	SW 6148	SW 7083
	LRV 20	LRV 63	LRV 5
	243-C5	207-C1	227-C7
<u>Option 17-B</u>		<u>Anew Gray</u>	<u>Status Bronze</u>
		SW 7030	SW 7034
		LRV 47	LRV 8
		243-C2	243-C7
<u>Option 17-C</u>		<u>Incredible White</u>	<u>Iron Ore</u>
		SW 7028	SW 7069
		LRV 74	LRV 6
		256-C4	251-C7
<u>Option 17-D</u>		<u>Accessible Beige</u>	<u>Sable</u>
		SW 7036	SW 6083
		LRV 58	LRV 8
		249-C1	198-C7
<u>Option 18-A</u>	<u>Dapper Tan</u>	<u>Downing Sand</u>	<u>Enduring Bronze</u>
(old scheme 3)	SW 6144	SW 2822	SW 7055
	LVR 22	LVR 52	LVR 7
	206-C5	311-C6	246-C7
<u>Option 18-B</u>		<u>Classical White</u>	<u>Black Fox</u>
		SW 2829	SW 7020
		LRV 76	LRV 7
		312-C4	244-C7
<u>Option 18-C</u>		<u>Shoji White</u>	<u>Sable</u>
		SW 7042	SW 6083
		LRV 74	LRV 8
		254-C4	198-C7
<u>Option 18-D</u>		<u>Roman Column</u>	<u>Van Dyke Brown</u>
		SW 7562	SW 7041
		LRV 88	LRV 7
		263-C1	249-C7

<u>Option # 19 A</u>	<u>Weathered Shingle</u>	<u>Steamed Milk</u>	<u>Polished Mahogany</u>
	SW 2841	SW 7554	SW 2838
	LRV 22	LRV 76	LRV 3
	313-C7	266-C1	313-C
<u>Option # 19 B</u>		<u>Ivory Lace</u>	<u>Van Dyke Brown</u>
		SW 7013	SW 7041
		LRV 79	LRV 7
		254-C3	249-C7
<u>Option # 19 C</u>		<u>Accessible Beige</u>	<u>Well-Bred Brown</u>
		SW 7036	SW 7027
		LRV 58	LRV 7
		249-C2	241-C7
<u>Option # 19 D</u>		<u>Alabaster</u>	<u>Enduring Bronze</u>
		SW 7008	SW 7055
		LRV 82	LRV 7
		255-C2	246-C7
<u>Option # 20 A</u>	<u>Sticks and Stones</u>	<u>Marshmallow</u>	<u>Fairfax Brown</u>
	SW 7503	SW 7001	SW 2856
	LRV 31	LRV 82	LRV 7
	283-C6	267-C1	315-C5
<u>Option # 20 B</u>		<u>Wool Skein</u>	<u>Van Dyke Brown</u>
		SW 6148	SW 7041
		LRV 63	LRV 7
		207-C1	249-C7
<u>Option # 20 C</u>		<u>Ivory Lace</u>	<u>Sable</u>
		SW 7013	SW 6083
		LRV 79	LRV 8
		254-C3	198-C7
<u>Option # 20 D</u>		<u>Neutral Ground</u>	<u>Turkish Coffee</u>
		SW 7568	SW 6076
		LRV 70	LRV 5
		261-C5	277-C3
<u>Option # 21 A</u>	<u>Hardware</u>	<u>Balanced Beige</u>	<u>Andiron</u>
(old scheme 4)	SW 6172	SW 7037	SW 6174
	LRV 23	LRV 46	LRV 5
	211-C5	249-C2	278-C6
<u>Option # 21 B</u>		<u>Moderne White</u>	<u>Forestwood</u>
		SW 6168	SW 7730
		LRV 74	LRV 5
		258-C6	278-C6
<u>Option # 21 C</u>		<u>Sedate Gray</u>	<u>Iron Ore</u>
		SW 6169	SW 7069
		LRV 61	LRV 6
		211-C1	251-C7
<u>Option # 21 D</u>		<u>Divine White</u>	<u>Black Fox</u>
		SW 6105	SW 7020
		LRV 72	LRV 7
		266-C4	244-C7

<u>Option # 22 A</u>	<u>Intelletual Gray 8</u>	<u>Wool Skein</u>	<u>Greenblack</u>
	SW 7045	SW 6148	SW 6994
	LRV 36	LRV 63	LVR 4
	245-C3	207-C1	251-C6
<u>Option # 22 B</u>		<u>Worldly Gray</u>	<u>Anonymous</u>
		SW 7043	SW 7046
		LRV 57	LRV 20
		245-C1	245-C5
<u>Option # 22 C</u>		<u>Grecian Ivory</u>	<u>Rock Bottom</u>
		SW 7541	SW 7062
		LRV 63	LRV 7
		247-C1	278-C2
<u>Option # 22 D</u>		<u>Useful Gray</u>	<u>Black Fox</u>
		SW 7050	SW 7020
		LRV 59	LRV 7
		246-C1	244-C7
<u>Option # 23 A</u>	<u>Mega Greige</u>	<u>Accessible Beige</u>	<u>Black of Night</u>
(old scheme 2)	SW 7031	SW 7036	SW 6993
	LRV 37	LRV 58	LRV 4
	243-C3	249-C1	251-C5
<u>Option # 23 B</u>		<u>Incredible White</u>	<u>Greenblack</u>
		SW 7028	SW 6994
		LRV 74	LRV 4
		256-C4	251-C6
<u>Option # 23 C</u>		<u>Ivory Lace</u>	<u>Black Fox</u>
		SW 7013	SW 7020
		LRV 79	LRV 7
		254-C3	244-C7
<u>Option # 23 D</u>		<u>Popular Gray</u>	<u>Tricorn Black</u>
		SW 6071	SW 6258
		LRV 61	LRV 3
		242-C1	251-C1
<u>Option # 24 A</u>	<u>Stone Lion</u>	<u>Only Natural</u>	<u>Sable</u>
	SW 7507	SW 7596	SW 6083
	LRV 38	LRV 67	LRV 8
	248-C3	266-C7	198-C7
<u>Option # 24 B</u>		<u>Antique White</u>	<u>Garden Gate</u>
		SW 6119	SW6167
		LRV 72	LRV 10
		263-C6	212-C7
<u>Option # 24 C</u>		<u>Nantucket Dune</u>	<u>Griffin</u>
		SW 7527	SW 7026
		LRV 54	LRV 13
		285-C2	241-C6
<u>Option # 24 D</u>		<u>Everyday White</u>	<u>Rockweed</u>
		SW 6077	SW 2735
		LRV 72	LRV 4
		260-C5	252-C1

<u>Option # 25 A</u>	<u>Universal Khaki</u>	<u>Casa Blanca</u>	<u>Otter</u>
	SW 6150	SW 7571	SW 6041
	LRV 40	LRV 76	LRV 6
	207-C3	264-C4	232-C7
<u>Option # 25 B</u>		<u>Aged White</u>	<u>Ripe Olive</u>
		SW 7571	SW 6209
		LRV 74	LRV 6
		261-C4	217-C7
<u>Option # 25 C</u>		<u>Pearly White</u>	<u>Black Fox</u>
		SW 7009	SW 7020
		LRV 77	LRV 7
		254-C2	244-C7
<u>Option # 25 D</u>		<u>Wool Skein</u>	<u>Garden Gate</u>
		SW 6148	SW 6167
		LRV 63	LRV 10
		207-C1	212-C7
<u>Option # 26 A</u>	<u>Gateway Gray</u>	<u>Nacre</u>	<u>Tricorn Black</u>
	SW 7644	SW 6154	SW 6258
	LVR 41	LVR 76	LRV 3
	247-C3	263-C2	251-C1
<u>Option # 26 B</u>		<u>Oyster White</u>	<u>Iron Ore</u>
		SW 7637	SW 7069
		LRV 72	LRV 6
		254-C7	251-C7
<u>Option # 26 C</u>		<u>Shoji White</u>	<u>Status Bronze</u>
		SW 7042	SW 7034
		LRV 74	LRV 8
		254-C4	243-7
<u>Option # 26 D</u>		<u>Gossamer Veil</u>	<u>Greenblack</u>
		SW 9165	SW 6994
		LRV 62	LRV 4
		238-C1	251-C6
<u>Option # 27 A</u>	<u>Svelte Sage</u>	<u>Ancient Marble</u>	<u>Connected Gray</u>
	SW 6164	SW 6162	SW 6165
	LRV 41	LRV 60	LRV 23
	212-C3	212-C1	212-C5
<u>Option # 27 B</u>		<u>Oyster White</u>	<u>Eclipse</u>
		SW 7637	SW 6166
		LRV 72	LRV 14
		254-C7	212-C6
<u>Option # 27C</u>		<u>Grecian Ivory</u>	<u>Mountain Road</u>
		SW 7541	SW 7743
		LRV 63	LRV 23
		247-C1	247-7
		<u>Ivory Lace</u>	<u>Garden Gate</u>
		SW 7013	SW 6167
		LRV 79	LRV 10
		254-C3	212-C7

<u>Option # 28 A</u>	<u>Favorite Tan</u>	<u>Downing Earth</u>	<u>Black Bean</u>
(old scheme 6)	SW 6157	SW 2822	SW 6006
	LRV 44	LRV 36	LRV 4
	210-C3	311-C6	252-C2
<u>Option # 28 B</u>		<u>White Duck</u>	<u>Roycroft Bronze Green</u>
		SW 7010	SW 2846
		LRV 74	LRV 5
		254-C5	314-C4
<u>Option # 28 C</u>		<u>Crisp Linen</u>	<u>Roycroft Bottle Green</u>
		SW 6378	SW 2847
		LRV 81	LRV 5
		264-C3	314-C5
<u>Option # 28 D</u>		<u>Cotton White</u>	<u>Black Fox</u>
		SW 7104	SW 7020
		LRV 87	LRV 7
		265-C1	244-C7
<u>Option # 29 A</u>	<u>Renwick Beige</u>	<u>Shoji White</u>	<u>Greenblack</u>
(old scheme 6)	SW 2085	SW 7042	SW 6994
	LVR 45	LRV 74	LRV 4
	309-C5	254-C4	251-C6
<u>Option # 29 B</u>		<u>Ivory Lace</u>	<u>Rockwood Shutter Green</u>
		SW 7013	SW 2809
		LRV 79	LRV 4
		254-C3	310-C1
<u>Option # 29 C</u>		<u>Creamy</u>	<u>Well-Bred Brown</u>
		SW 7012	SW 7027
		LRV 81	LRV 7
		261-C3	241-C7
<u>Option # 29 D</u>		<u>Reliable White</u>	<u>Black Bean</u>
		SW 6091	SW 6006
		LRV 74	LRV 4
		267-C6	252-C2
<u>Option # 30 A</u>	<u>Balanced Beige</u>	<u>Wool Skein</u>	<u>Smokehouse</u>
	SW 7037	SW 6148	SW 7040
	LRV 46	LRV 63	LRV 13
	249-C2	207-C1	249-C6
<u>Option # 30 B</u>		<u>Accessible Beige</u>	<u>Black Bean</u>
		SW 7036	SW 6006
		LRV 58	LRV 4
		249-C2	252-C2
<u>Option # 30 C</u>		<u>Aged White</u>	<u>Black Fox</u>
		SW 9180	SW 7020
		LRV 74	LRV 7
		261-C4	244-C7
<u>Option # 30 D</u>		<u>Simple White</u>	<u>Greenblack</u>
		SW 7021	SW 6994
		LRV 70	LRV 4
		260-C7	251-C6

<u>Option # 31 A</u>	<u>Beach House</u>	<u>Alabaster</u>	<u>Tricorn Black</u>
	SW 7518	SW 7008	SW 6258
	LRV 47	LRV 82	LRV 3
	288-C3	255-C2	251-C1
<u>Option # 31 B</u>		<u>Panta White</u>	<u>Rockweed</u>
		SW 6147	SW 2735
		LRV 77	LRV 4
		266-C2	252-C1
<u>Option # 31 C</u>		<u>Pearly White</u>	<u>Raisin</u>
		SW 7009	SW 7630
		LRV -77	LRV 3
		254-C2	252-C3
<u>Option # 31 D</u>		<u>Crisp Linen</u>	<u>Black Fox</u>
		SW 6378	SW 7020
		LRV 81	LRV 7
		264-C3	244-C7

Painting Information
Country Walk Home Owner's Association
Architecture Control Committee

Painting the exterior of your home beautifies, revives and protects your home better than any other home improvement project. At a minimum, the things that should be done are:

- Power wash the house to remove mildew, dirt and chalking ensuring proper paint adhesion.
- Repair or replace rotted or damaged wood including brick mold around doors and windows; consider PVC in lieu of wood where possible.
- Caulk body, eaves, windows and door frames to seal off moisture, drafts and siding where seams were separated.
- Re-glaze windows where missing or loose to seal out moisture and prevent deterioration of the mullions.
- Scrape and sand all loose or peeling paint to provide an appropriate bonding surface for application of the primer and finish coats.
- Prime bare wood for proper finish coat adherence.
- Spot prime where paint is peeling.
- Repaint the House.

Sherwin-Williams put this book together for the Country Walk ACC. Ten of the 31 approved house body colors are represented along with four choices of trim and accents. Following these pages is a complete list of all approved colors.

If you're a new home owner or someone who has never had their house painted before, you may not be familiar with the ACC rules regarding what is included in the body, trim and accent. The following explanations should help and if not you can always contact your ACC to get clarification.

The body of your home includes the walls covered with siding, stucco, rock, or brick. It also includes garage doors and bay walls. It does not include corner boards, porch ceilings. Note, rock and brick should not be painted.

The trim of your home includes corner boards, shutters, boards surrounding windows (sashes, mullions, and casing), board and batten, porch beams, porch columns, porch ceilings and gutters and down spouts.

Accent items include shutters, metal roofs over bay windows, front doors, staggered shakes, and architectural round shingles or other architectural details. Note: staggered shakes, architectural round shingles or other architectural details can be treated as accents or trim and stated on your request and you may paint them with either another trim color or another accent color.

The roof vent pipes and the chimney caps must be painted a flat black. There are no exceptions.

Regardless of whether you are determining if you want to hire a professional or do the job yourself, you should know the following:

- Painting the exterior of your home is a big job so determine if you have the knowledge and time to properly prepare the house for paint. You must be able to:
 - ✓ Be patient, it's going to take you weeks or even months to do this work yourself.
 - ✓ Replace rotted wood.
 - ✓ Pressure wash the house to remove mildew, dirt and chalking for proper adhesion and be careful not to get water between pieces of siding and other structural coverings.
 - ✓ Caulk the body, eaves, windows and door frames to seal off moisture, drafts.
 - ✓ Re-glaze windows where missing or lease to seal out moisture and prevent deterioration of the mullions.
 - ✓ Scraping and sanding of all loose and peeling paint to provide an adequate bonding surface for application of the primer and finish coat.
 - ✓ Apply primers to bear wood, again for proper finish coat adherence.
 - ✓ Repair bricks molds, window nosing, fascia, soffit and other trim.

- If you hire a professional painter, expect to pay from \$1,000 to \$5,500 or more, depending on the size and condition of your house. Regardless of whether you hire a pro or do it yourself, painting your house is something you won't want to repeat in a few years. With this in mind, here are 10 critical rules that will ease the work and help ensure a beautiful, lasting result.

1. Don't skimp on materials. Pay for top-quality paint, primer and caulking compound. Top-quality paint lasts longer, and flows and covers better than poor-quality paint. Buy paint that has a lifetime warranty against defects in the finish. Remember, you get what you pay for and you want to use 100 percent acrylic paint.

Flat finishes, preferred for siding, do a good job of hiding defects and irregularities. Satin and semi-gloss enamels, used for trim, are more durable and easier to wash. Although that is mostly true but with lighter colors, you should talk to your painter and take their advice.

2. Do the necessary preparation. For paint to adhere well, it must be applied to a surface that is clean, dry and not flaking or peeling. Depending on the condition of existing siding and trim, this often means considerable scraping and sanding may be required before you can paint.

Begin by washing the surfaces. You can use a hose and a scrub brush with water and detergent, or a pressure washer. If you use a pressure washer, you must be careful not to drive water deeply into the joints between siding or erode the surface of the wood with the high-pressure water spray.

3. To remove loose, flaking paint, you'll need a scraper. Then, for removing tougher paint and smoothing the surface, a 5-inch disc power sander or a random-orbit sander will work well. Start with 60-grit sandpaper and follow-up with 100-grit sandpaper.

Remove loose paint and smooth the surface. Use a putty knife and wood filler to fill cracks and holes. Let the filler dry, and then sand these areas again. Brush off all of the dust, caulk the joints, and allow the caulk to dry before applying primer.

4. Don't skimp on coats of paint. Begin with a high-quality oil-alkyd primer if you're painting over bare wood or metal for your base coat. Some painters like to tint the primer toward the final paint color to minimize the need for two finish coats of paint. Others prefer to tint the primer to a contrasting color, which will highlight any spots where the final coats haven't completely covered.

Apply the first finish coat and, after it becomes tacky, apply a second top coat.

5. Use the right tools. A high-quality brush, roller and, for some houses, an airless sprayer can be rented at most home improvement centers or tool rental outlets. The easiest way to apply primer and paint to textured surfaces is to spray it on with an airless sprayer, and then back-roll it by hand with a roller to ensure adhesion.

If you have never used an airless sprayer, pay close attention to the equipment's directions and gain a little experience by painting a less-conspicuous side of the house first. Work from a 5-gallon paint bucket and use a paint strainer so paint doesn't clog the sprayer.

6. Don't paint your house yourself unless you have the time, tools, skills and stamina to do the work. Depending on the size and height of your house and the condition of the existing siding, preparing and painting a house on your own can be a tedious, difficult job.

7. Wait for temperate weather. Don't paint on hot days, in the rain, or during windy or dusty weather. Ideal temperatures for painting are between 50 and 90 degrees Fahrenheit. Hot weather causes the paint to dry too quickly, such as the direct sun. When possible, follow the shade. Temperatures below 50 degrees may prevent the paint from adhering to the surface properly. Dampness or dew can bubble surfaces.

8. Cover everything else. Protect decks, shrubs, gardens, patios and walkways from paint spills and splatters with drop cloths or plastic sheeting. This will save you from big cleanup problems later. If you use an airless paint sprayer, masking and covering will be absolutely imperative – overspray can even coat your neighbors' cars.

9. Paint using proven techniques. If you're a painting novice, do your homework. You can find lots of free information on the web, including videos by pros and experts that show specific techniques.

Work from the top down, starting with overhangs so fresh paint won't drip on newly painted surfaces. Paint the siding, and when that's dry, tape around windows and doors, and paint the trim. As soon as you're finished painting the trim, remove painter's tape or masking tape so it won't leave a residue. After all of the paint has dried, touch up where paint hasn't covered fully.

10. Get at least three detailed bids from various painting contractors and ask the professional painters for a copy of his / her business license and perhaps more important, an Accord Certificate of Liability Insurance and Workers Compensation. You should also ask references of past customers and if possible, contact several of them and determine if the customer was satisfied with their work and if not, why not.

Why do I need them to have these insurances you ask? The average homeowner will never know the answer to that question until a contractor has a problem resulting in damage to their home or property. This applies to any contractor. One assumption that homeowners have is that their homeowners insurance will cover them if something happens while someone is working on their house. The fact is that in most cases if you hire a contractor licensed or not to work on your home and he is not properly insured the insurance company is under no obligation to help you with the cost to repair damages caused by that person or company. If you doubt this take the time to read your policy or ask your insurance agent. You will be glad you did.